




COOKTOP PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)

30" Slide-In
Electric Range




Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10165716	Use & Care Guide
	W10166918	Wiring Diagram
	W10165721	Installation Instructions
2		Cooktop
	74010895	White
	74011071	Black
3	12001676	Kit, Hardware
4	74007159	Element RF/LR(2)8"
5	74007158	Element LF/RR(2)6"
6	74005759	Tube, Vent Upper
7	74003357	Screw (4)
8	74006046	Bottom, Burner Box
9	74001212	Bowl, Drip(Chr 6")
10	74001213	Bowl, Drip(Chr 8")
11	74010894	Bracket, Burner Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	7730P011-60	Lens
2	W10169863	Panel, Control
	W10169864	Black
	W10169864	White
3	7101P309-60	Screw, Switch (10)
4		Switch, Infinte
	7403P239-60	8" (RF/LR)(2)
	7403P238-60	6" (LF/RR) (2)
5		Control W/Overlay
	W10169864	White
	W10169863	Black


Illus. No.	Part No.	DESCRIPTION
6		End Cap
	74010835	Left Black
	74004822	Left White
	74010834	Right Black
	74004821	Right White
7		Screw, End Cap
	74009537	Black
	74009540	White
8		Switch, Rocker
	74008718	Black
	74008717	White

Illus. No.	Part No.	DESCRIPTION
9	74004288	Screw, Control
10	74004785	Support, Control Panel
11	7101p338-60	Screw, Support (4)
12		Shield, Heat
	74001337	Black
	74001338	White
13	74004153	Light, Indicator
14		Knob (4)
	74003612	Black
	74003611	White

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Panel, Shield
	74010821	Left
	74010822	Right
2	74010897	Latch Assembly
3		Lever, Lock
	74002974	Gray
	74001075	Black
4	74011465	Main Back
5	74006096	Cover, Main Wire
6	74010815	Extension, Back
7	Y700502	Screw
8	74006364	Insulator, Cord
9	74005264	Panel, Access
11	74010823	Fan, Cooling
12	74008298	Block, Bare Wire
13	74004223	Connector, Cable
14	74003040	Element, Broil
15	74004943	Sensor, Oven
16	W10165822	Tube, Vent Lower
17	74010886	Tube, Vent Upper

Illus. No.	Part No.	DESCRIPTION
18	71001394	Screw (4)
19	74010817	Holder, Vent Tube
20	74008597	Smoke Eliminator
21	W10165724	Plate, Smoke Elm.
22	74010885	Light Assembly
23	74004180	Bracket,Pwr Supply
24	7407P103-60	Bulb, Oven
25		Trim, Side
	74010832	White (2)
	74010831	Black (2)
26	74003976	Screw,Shoulder (4)
27	74010883	Element, Bake
28	74010884	Support, Oven Rear
29	71001394	Screw
30	74011142	Hinge (2)
31	7101P112-60	Screw, Hinge (4)
32	74010818	Switch, Hi-Limit
33	74003975	Screw, Lever (2)
34	74010820	Extention, Shield
35	74003386	Support, Element

Illus. No.	Part No.	DESCRIPTION
36	74010805	Leg, Leveling
37	74010899	Pedestal, Bottom
38	74010882	Pedestal, Front
39	74007129	Support
40	74003565	Runner, Drawer (2)
41	74004078	Roller, Drawer (2)
42	74005231	Shaft, Roller (2)
43	74005230	Nut, Lock (2)
44	74006522	Retainer, Bottom
45	74005564	Bracket, Anti-Tip
46	7101P124-60	Screw, w/Washer
47	74010812	Support, Ov Bottom
48	74003976	Screw,Shoulder (2)
49	74010807	Cover, Front


INSULATION

74010987	Insulation, Wrap
W10165725	Insulation, Back
74011207	Insulation, Oven Bottom

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	W10165729	Trim, Door Top
	W10165726	Black
	W10165726	White
2	74011674	Screw, Handle (2)
3	74011457	Baffel, Retainer
4	74001530	Screw 8AB 1/2
5	74003645	Glass, Inner (2)
6	74005546	Spacer, Rubber
7	74001574	Nut, Snap (4)
8	74011456	Lining, Door
9	74011458	Bracket, Glass (2)
10	74003647	Insulation, Door
11	Y700502	Screw


Illus. No.	Part No.	DESCRIPTION
12	74009699	Bracket, Handle
	74009699	Left
	74009698	Right
13	74004224	Tape, White
14	74009693	Trim, Door Side
	74009693	Black, Left
	74009695	White, Left
	74009692	Black Right
	74009694	White, Right
15	74009014	Tape, Double Sided
	74009014	White
	74009025	Black
16	74009687	Trim, Door Bottom
	74009687	White
	74009686	Black

Illus. No.	Part No.	DESCRIPTION
17	74009540	Screw, Trim
	74009540	White
	74009539	Black
18	7201P046-60	Seal, Door
19	W10165730	Glass, Door
	W10165730	White
	W10165731	Black
	(Order Items 13 & 21 When Replacing Door Glass)	
20	74008322	Handle, Door
	74008322	White
	74008318	Black
21	74003664	Tape, Foil
22	8303811	Nameplate, Logo

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER AND RACK PARTS

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	74001757	Rack, Oven (2)
2	74008333	Drawer, Storage
3	74004310	Screw, Panel
4	74010896	Bracket, Drawer

Illus. No.	Part No.	DESCRIPTION
5		Panel, Drawer
	74003407	White
	74003701	Black
6		Screw, Panel
	74009540	White
	74009539	Black

Illus. No.	Part No.	DESCRIPTION
7	74005230	Nut, Lock
8	2404F030-51	Lining, Drawer
9	74005546	Spacer, Rubber
10	74004078	Roller, Drawer (2)
11	74005231	Shaft, Roller (2)
12	7103P082-60	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RY160LXTQ0, RY160LXTB0
(White) (Black)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

Illus. No.	Part No.	DESCRIPTION
<u>REFINISHING MATERIAL</u>		
	799832	Kit, Porcelain Repair (White)
	242756	Touch-Up Self-Clean(1/2 Pt)
	261582	Grease

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass

WIRING HARNESS PARTS

74010890	Harness, Sensor
74010891	Coil, Harness (Rt)
74010893	Coil,Harness (Lt)
W10166773	Harness, Main
74011206	Cable, Assy.(Flex)
74006811	Clip, Wire
7101P027-60	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST